



www.DanaherMotion.com

*Installation Instructions for SLO-SYN[®]
MODEL SS2000MD4-M
Microstep Translator/Drive*

400030-060 Rev H



TABLE OF CONTENTS

<i>SECTION 1 INTRODUCTION</i>	5
1.1 USING THIS MANUAL	5
1.2 PRODUCT FEATURES	5
<i>SECTION 2 EXPRESS START UP</i>	6
<i>SECTION 3 INSTALLATION</i>	7
3.1 MOUNTING	7
3.2 TERMINAL LOCATIONS AND ASSIGNMENTS	8
3.3 MOTOR CONNECTIONS	9
3.4 POWER INPUT	11
<i>SECTION 4: SPECIFICATIONS</i>	12
4.1 MECHANICAL SPECIFICATIONS	12
4.2 ELECTRICAL SPECIFICATIONS	12
4.3 ENVIRONMENTAL SPECIFICATIONS	12
4.4 MOTOR COMPATIBILITY	12
4.5 CURRENT SETTINGS	14
4.6 AUTOMATIC CURRENT REDUCTION	14
4.7 STEP RESOLUTION	14
4.8 SIGNAL SPECIFICATIONS	15
4.8.1 Terminal Assignments	15
4.8.2 Signal Descriptions	16
4.8.4 Timing Requirements	16
4.9 INDICATOR LIGHTS	17
<i>SECTION 5: TORQUE VERSUS SPEED CHARACTERISTICS</i>	18
5.1 MOTOR PERFORMANCE	18
5.2 TYPICAL TORQUE VERSUS SPEED CURVES	19
<i>SECTION 6: TROUBLESHOOTING</i>	28
<i>APPENDIX A: TROUBLESHOOTING ELECTRICAL INTERFERENCE PROBLEMS</i>	29

SAFETY

- ! Only qualified personnel should install or service this equipment.
- ! Before performing any work on the unit, allow at least five minutes for the capacitors to discharge fully.
- ! Voltage is present on unprotected pins when unit is operational.
- ! Motors powered by this drive may develop extremely high torque. Be sure to disconnect power to this drive before performing any mechanical work.



This unit is designed for 24 to 40 VDC input only (see Electrical Specifications).

WARRANTY AND LIMITATION OF LIABILITY

Danaher Motion (the "Company") warrants to the first end user purchaser (the "purchaser") of equipment manufactured by the Company that such equipment, if new, unused and in original unopened cartons at the time of purchase, are free from defects in material and workmanship under normal use and service for a period of one year from date of shipment from the Company's factory or a warehouse of the Company in the event that the equipment is purchased from the Company or for a period of one year from the date of shipment from the business establishment of an authorized distributor of the Company in the event that the equipment is purchased from an authorized distributor.

THE COMPANY'S OBLIGATION UNDER THIS WARRANTY SHALL BE STRICTLY AND EXCLUSIVELY LIMITED TO REPAIRING OR REPLACING, AT THE FACTORY OR A SERVICE CENTER OF THE COMPANY, ANY SUCH EQUIPMENT OR PARTS THEREOF WHICH AN AUTHORIZED REPRESENTATIVE OF THE COMPANY FINDS TO BE DEFECTIVE IN MATERIAL OR WORKMANSHIP UNDER NORMAL USE AND SERVICE WITHIN SUCH PERIOD OF ONE YEAR. THE COMPANY RESERVES THE RIGHT TO SATISFY SUCH OBLIGATION IN FULL BY REFUNDING THE FULL PURCHASE PRICE OF ANY SUCH DEFECTIVE EQUIPMENT. This warranty does not apply to any equipment which has been tampered with or altered in any way, which has been improperly installed or which has been subject to misuse, neglect or accident.

THE FOREGOING WARRANTY IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, and of any other obligations or liabilities on the part of the Company; and no person is authorized to assume for the Company any other liability with respect to equipment manufactured by the Company. The Company shall have no liability with respect to equipment not of its manufacture. **THE COMPANY SHALL HAVE NO LIABILITY WHATSOEVER IN ANY EVENT FOR PAYMENT OF ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR INJURY TO ANY PERSON OR PROPERTY.**

Written authorization to return any equipment or parts thereof must be obtained from the Company. The Company shall not be responsible for any transportation charges.

IF FOR ANY REASON ANY OF THE FOREGOING PROVISIONS SHALL BE INEFFECTIVE, THE COMPANY'S LIABILITY FOR DAMAGES ARISING OUT OF ITS MANUFACTURE OR SALE OF EQUIPMENT, OR USE THEREOF, WHETHER SUCH LIABILITY IS BASED ON WARRANTY, CONTRACT, NEGLIGENCE, STRICT LIABILITY IN TORT OR OTHERWISE, SHALL NOT IN ANY EVENT EXCEED THE FULL PURCHASE PRICE OF SUCH EQUIPMENT.

Any action against the Company based upon any liability or obligation arising hereunder or under any law applicable to the sale of equipment, or the use thereof, must be commenced within one year after the cause of such action arises.

Reconfiguration of the circuit in any fashion not shown in this manual voids the Warranty.

Failure to follow the installation guidelines as described in Section 3 voids the Warranty.

SECTION 1 INTRODUCTION

1.1 USING THIS MANUAL

It is important that you understand how this SLO-SYN SS2000MD4-M Translator/Drive is installed and operated before you attempt to use it.

Read this manual completely before installing this unit.

This manual is an installation and operating guide to the SLO-SYN SS2000MD4-M Translator/Drive. Section 1 is an overview of the Drive and its features. Section 2 provides the steps necessary to place the drive into operation. General wiring guidelines, physical mounting of the unit and connections to the drive are covered in Section 3.

Complete specifications, (electrical, mechanical, environmental) are listed in Section 4. The procedure for setting the motor current level is also covered in this section.

Torque versus speed characteristics with appropriate SLO-SYN Stepper Motors are given in Section 5. Section 6, Troubleshooting, outlines procedures to follow if the Translator/Drive fails to operate properly.

Appendix A provides procedures for troubleshooting electrical interference problems.

1.2 PRODUCT FEATURES

The SLO-SYN SS2000MD4-M Translator/Drive is a bipolar, adjustable speed, two-phase PWM drive which uses hybrid power devices. It can be set to operate a step motor in microstep mode at up to 20,000 microsteps per revolution. The maximum running speed is 3,000 rpm. To reduce the chances of electrical noise problems, the control signals are optically isolated from the drive circuit. Features include:

- ! Switch selectable current levels of 1.0 through 3.5 amperes
- ! Full short circuit protection (phase-to-phase and phase-to-ground)
- ! Undervoltage and transient overvoltage protection
- ! Efficient thermal design
- ! Optically isolated inputs
- ! Windings Off capability
- ! Automatic Current Reduction
- ! Switch selectable step resolution
- ! Compact size
- ! Sturdy all-aluminum mounting base

SECTION 2 EXPRESS START UP

The following instructions define the minimum steps necessary to make your **Drive** operational.



Always disconnect the power to the unit before connecting or disconnecting the motor leads. FAILURE TO DO THIS WILL RESULT IN A SHOCK HAZARD AND MAY DAMAGE THE DRIVE.

Always operate the unit with the Motor and the Drive enclosure GROUNDED. Be sure to twist together the wires for each motor phase as well as those for the DC input. Six twists per foot (0.3 m) is a good guideline.

1. Check to see that the motor used is compatible with the drive. Refer to Section 4.4 for a list of compatible motors.
2. Set the correct current level for the motor being used per the instructions in Section 4.5. **Heat sinking may be required to maintain case temperature below +70° C (+158° F).**
3. Select the appropriate step resolution and set the switches as described in Section 4.7.
4. Wire the motor per the "Motor Connections" description in Section 3.2.
5. Connect the power source to the DC input terminal strip. Be sure to follow the instructions for connecting the filter capacitor as described in Section 3.2, under Power Input.



If the motor operates erratically, refer to Section 5, "Torque Versus Speed Characteristics".

Clockwise and counter-clockwise directions are properly oriented when viewing the motor from the end opposite the mounting flange.

SECTION 3 INSTALLATION

3.1 MOUNTING

The SLO-SYN Drive is mounted by fastening its mounting brackets to a flat surface. Dimensions are shown in Figure 3.1. If the drive assembly is mounted against a bulkhead, be sure to apply a thin coating of thermal compound between the drive and the mounting surface before fastening the unit in place. Do not use too much thermal compound. It is better to use too little than too much.




Figure 3.1, Mounting Diagram




Case temperature must not exceed +70° C (+158° F).

When selecting a mounting location, it is important to leave at least two inches (51mm) of space around the top, bottom and sides of the unit to allow proper airflow for cooling.


It is also important to keep the drive away from obvious noise sources. If possible, locate the drive in its own metal enclosure to shield it and its wiring from electrical noise sources. If this cannot be done, keep the drive at least three feet (0.9 m) from any noise sources.

3.2 TERMINAL LOCATIONS AND ASSIGNMENTS

Figure 3.2 shows the terminal locations for the SLO-SYN SS2000MD4-M Translator/Drive.



I/O Connector (J1)



Motor And Power Supply Connector (J2)

Figure 3.2, Terminal Locations

3.3 MOTOR CONNECTIONS

All motor connections are made via the 6-terminal strip. Terminal assignments are given below. Motor connections are shown in Figure 3.3.

J2 Pin	Assignment
1	M1 (Phase A+)
2	M3 (Phase A-)
3	M4 (Phase B+)
4	M5 (Phase B-)




Motor phase A is M1 and M3 and motor phase B is M4 and M5. The motor frame must be grounded.

Cabling from the drive to the motor should be done with a shielded, twisted-pair cable. The wires for each motor phase should be twisted together about six times per foot (0.3 m).

Danaher Motion offers the following motor cable configurations. These cables have unterminated leads on both ends.

Length	Part Number
10 ft (3 m)	216022-031
25 ft (7.6 m)	216022-032
50 ft (15.2 m)	216022-033
75 ft (22.8 m)	216022-034

Figure 3.3 shows the possible motor wiring configurations.



***These leads must be insulated and isolated from other leads or ground.**

Circled letters identify terminals for connector motors, numbers identify those for terminal box motors.

Figure 3.3, Motor Wiring Configurations

3.4 POWER INPUT


The DC input power is connected to terminals 5 and 6 of the terminal strip. Terminal 5 [Vm(+)] is the power supply plus (+) connection and pin 6 [Vm (-)] is the power supply minus (-) connection.

An unregulated supply like one shown in Figure 3.4 is preferable. If a regulated supply is used, it must be capable of operating with the added filter capacitor. A switching regulated supply may not be suitable for use with this drive. It is important that the capacitor (C1) be connected within three feet (0.9 meter) of the input terminals. The capacitor must be of the correct value and have the proper current and voltage parameters.

It is recommended that the power supply leads be twisted together using approximately six twists per foot (0.3 m).



If the power supply is grounded, it must only be grounded on the negative side or the short circuit protection will not operate properly.



The cable between the filter capacitor (C1) and the drive should be twisted using approximately six twists per foot (0.3 m)). Maximum wire length is three feet.

Use #16 AWG or larger wire.

Figure 3.4

Typical Power Supply For A Single Drive Application

Components

F1	1.5 ampere time delay, 250 volt
R1	5 ohm surge limiter, Dale 7SS5 or equivalent
T1	130 VA, 24 VAC output
BR1	General Instrument GBPC3502 or equivalent
C1	4700 µf, 5.5 ampere 20 kHz, 63 V rated, United Chemcon 53D472F063HS6 or equivalent

SECTION 4: SPECIFICATIONS

4.1 MECHANICAL SPECIFICATIONS

Size	
(Inches)	1.56 H x 4.13 W x 3.25 D
(mm)	40 H x 105 W x 83 D
Weight	0.6 pounds (272 grams)

4.2 ELECTRICAL SPECIFICATIONS

DC Input Range	24 VDC min., 40 VDC max.
DC Current	see Motor Table
Drive Power Dissipation (Worse Case)	35 watts

4.3 ENVIRONMENTAL SPECIFICATIONS

Temperature	
Operating	+32° F to +122° F (0° C to +50° C) free air ambient, Natural Convection. Maintain a maximum heat sink temperature of 158° F (70° C). Forced-air cooling may be required.
Storage	-40° F to +167° F (-40° C to +75° C)
Humidity	95% max. noncondensing
Altitude	10,000 feet (3048 m) max.

4.4 MOTOR COMPATIBILITY

Motor Types	Superior Slo-Syn M and KM Series
M Series Frame Sizes	M061 (NEMA 23D) through M092 (NEMA 34)
KM series frame sizes	KML061 (NEMA 23) through KML093 (NEMA 34)
Number of Connections ..	4, 6, 8
Minimum Inductance	0.5 millihenry
Maximum Resistance	= 0.25 x VDC Supply/I Setting

Example:

$$\begin{aligned} \text{VDC} &= 30 & \text{I Setting} &= 3.5 \\ \text{R max.} &= 0.25 \times 30/3.5 = 2.1 \text{ ohms} \end{aligned}$$



Do not use larger frame size motor than those listed, or the drive may be damaged. If a larger frame size motor must be used, consult the factory for recommendations.



Maximum resistance is total of motor plus cable.

MOTORS FOR USE WITH THE SS2000MD4-M TRANSLATOR/DRIVE

Motor	Winding	Connection	Current Setting (Amperes)	Power Supply Current	
				Standstill (Amps. DC)	Maximum (Amps. DC)
M061	08	Series	2.5	1.0	2.0
M061	08	Parallel	3.5	1.0	2.0
M062	09	Series	3.0	1.0	2.5
M062	09	Parallel	3.5	1.0	3.5
M063	09	Series	3.0	1.5	2.0
M063	09	Parallel	3.5	1.0	3.5
M091	09	Series	3.0	1.0	1.5
M091	09	Parallel	3.5	1.5	3.0
M092	09	Series	3.0	1.5	2.0
M092	09	Parallel	3.5	1.0	3.0
KML060FO8	-	-	3.5	1.0	2.0
KML060F11	-	-	3.5	1.0	2.0
KML061FO5	-	-	2.5	1.2	1.5
KML061F11	-	-	3.5	1.0	3.0
KML062F07	-	-	3.0	1.0	2.5
KML062F13	-	-	3.5	1.0	4.0
KML063F07	-	-	3.0	1.5	2.0
KML063F13	-	-	3.5	1.0	4.0
KML091F07	-	-	3.0	1.0	2.0
KML091F13	-	-	3.5	1.0	4.0
KML092F07	-	-	3.0	1.5	2.5
KML092F13	-	-	3.5	1.0	4.0

Power supply currents shown are measured at the output of the rectifier bridge in Figure 3.4.

M061, M062 and M063 motors listed include LS, LE, CS, FC and FD versions. M091 and M092 motors include FC and FD versions with 6 or 8 leads. Motors with windings other than those listed can be used as long as the current ratings listed on the motors are not exceeded.

All KML motors listed have 4 leads.

4.5 CURRENT SETTINGS

The proper current setting for each motor is shown on the individual torque vs. speed curves. Use this current level to obtain the torque shown. Switches 1 through 5 are used to select the current level. Select the desired operating current by setting the appropriate switch to position 1 (ON). The OFF position is labeled "0". Only one switch should be ON. If two or more switches are ON, the one that selects the highest current level is the active switch. The switch settings are:

Position	Current (amperes)
None	1.0
1	1.5
2	2.0
3	2.5
4	3.0
5	3.5

4.6 AUTOMATIC CURRENT REDUCTION

When switch #6 is in the OFF position, the current at standstill goes to 50% of the selected level. This occurs between 1 and 2 seconds after the last pulse is received. When switch #6 is in the ON position, the current at standstill remains at full value.

4.7 STEP RESOLUTION

The number of pulses per revolution is selected using positions 7 and- 8 of the switch described in Section 4.5. The following chart shows the correct switch setting for each available step resolution.

Switch Position		Step Resolution	Pulses Per Revolutiion
7	8		
0 (OFF)	0 (OFF)	1/2	400
1 (ON)	0 (OFF)	1/10	2,000
0 (OFF)	1 (ON)	1/25	5,000
1 (ON)	1 (ON)	1/100	20,000




Figure 4.1
Switches For Setting Current Level
And Step Resolution

4.8 SIGNAL SPECIFICATIONS

4.8.1 Terminal Assignments

All connections are made via the 4-pin terminal strip.

J1 Pin	Assignment
1	OPTO
2	PULSE
3	DIR
4	AWO

4.8.2 Signal Descriptions

- OPTO** Opto-Isolator Supply
User supplied power for the opto-isolators.
- PULSE** Pulse Input
A low to high transition on this terminal advances the motor one step.
The step size is determined by the Step Resolution switch setting.
- DIR** Direction Input
When this signal is high, motor rotation will be clockwise. Rotation will be counter-clockwise when this signal is low.
Clockwise and counter-clockwise directions are properly oriented when viewing the motor from the end opposite the mounting flange.
- AWO** All Windings Off Input
When this signal is low, AC and DC current to the motor is zero.
There is no holding torque when the AWO signal is low.




If you are using the drive with an SS2000I or SS2000I-V control, the READY input and the OPTO input on the control must be jumpered together.

4.8.3 Level Requirements

- OPTO**
Voltage 4.5 to 6.0 VDC
Current..... 16 mA per signal used
- Other Signals**
Voltage
Low ≤ 0.8 VDC
 ≥ 0.0 VDC
High \leq OPTO
 \geq OPTO - 1 volt
- Current
Low ≤ 16 mA
High ≤ 0.2 mA

4.8.4 Timing Requirements

- PULSE**
Max. Frequency 500 kHz
Max. Rise And
Fall Times 1 microsecond
Min. Pulse Width 1 microsecond
- Other Signals**
Response Time 50 microseconds



Suggested Methods For Control Interface
Figure 4.2

4.9 INDICATOR LIGHTS

"FAULT" LED, Red

Lights to indicate over current condition. This condition is caused by motor wiring errors or a ground fault. Recovery from over current condition requires removing and then reapplying the power.

SECTION 5: TORQUE VERSUS SPEED CHARACTERISTICS

5.1 MOTOR PERFORMANCE


All stepper motors exhibit instability at their natural frequency and harmonics of that frequency. Typically, this instability occurs at speeds between 50 and 1000 full steps per second and, depending on the dynamic motor load parameters, cause excessive velocity modulation or improper positioning. This type of instability is represented by the open area at the low end of each Torque vs. Speed curve.

There are also other instabilities which may cause a loss of torque at stepping rates outside the range of natural resonance frequencies. One such instability is broadly defined as mid-range instability. Usually, the damping of the system and acceleration/deceleration through the resonance areas aid in reducing instability to a level that provides smooth shaft velocity and accurate positioning. If instability does cause unacceptable performance under actual operating conditions, the following techniques can be used to reduce velocity modulation.


- 1) Avoid constant speed operation at the motor's unstable frequencies. Select a base speed that is above the motor's resonant frequencies and adjust acceleration and deceleration to move the motor through unstable regions quickly.
- 2) The motor winding current can be reduced as described in Section 4.5. Lowering the current will reduce torque proportionally. The reduced energy delivered to the motor can decrease velocity modulation.
- 3) Using another step resolution may provide smoother operation and reduce the effects of mid range instability. **Microstepping changes the shaft speed for a given pulse input rate.**

5.2 TYPICAL TORQUE VERSUS SPEED CURVES


The test conditions used when obtaining the torque versus speed data are listed in the lower left-hand corner of each curve.




1/10 MICROSTEP M061LE08, ETC., MOTORS, SERIES CONNECTED




1/10 MICROSTEP M061LE08, ETC., MOTORS, PARALLEL CONNECTED




**1/10 MICROSTEP
M062LE09, ETC., MOTORS, SERIES CONNECTED**




**1/10 MICROSTEP
M062LE09, ETC., MOTORS, PARALLEL CONNECTED**




**1/10 MICROSTEP
M063LE09, ETC., MOTORS, SERIES CONNECTED**




**1/10 MICROSTEP
M063LE09, ETC., MOTORS, PARALLEL CONNECTED**




**1/10 MICROSTEP
M091-FD8109, ETC., MOTORS, SERIES CONNECTED**




**1/10 MICROSTEP
M091-FD8109, ETC., MOTORS, PARALLEL CONNECTED**




**1/10 MICROSTEP
M092-FD8109, ETC., MOTORS, SERIES CONNECTED**




**1/10 MICROSTEP
M092-FD8109, ETC., MOTORS, PARALLEL CONNECTED**




KML060F08, 3.5 Amp, 36V Bus




KML060F11, 3.5 Amp, 36V Bus




KML061F05, 3.0 Amp, 36V Bus




KML061F11, 3.5 Amp, 36V Bus




KML062F07, 3.0 Amp, 36V Bus




KML062F13, 3.5 Amp, 36V Bus




KML063F07, 3.0 Amp, 36V Bus




KML063F13, 3.5 Amp, 36V Bus




KML091F07, 3.5 Amp, 36V Bus



KML091F13, 3.5 Amp, 36V Bus



KML092F07, 3.5 Amp, 36V Bus



KML092F13, 3.5 Amp, 36V Bus

SECTION 6: TROUBLESHOOTING

WARNING!

Motors connected to this drive can develop high torque and large amounts of mechanical energy.

Keep clear of the motor shaft and all parts mechanically linked to the motor shaft.

Turn off all power to the drive before performing work on parts that are mechanically coupled to the motor.

If installation and operating instructions have been followed carefully, this unit should operate correctly. If the motor fails to step properly, use the following checklist to locate and correct the problem.

In General

- ! Check all installation wiring carefully for wiring errors or poor connections. Check to see that the proper voltage levels are being supplied to the unit. Be sure that the motor is a correct model for use with this unit.

Specifically

IF MOTOR DIRECTION IS REVERSED, Check For:

Reversed connections to the Motor Connector. Reversing the phase A or the phase B connections reverses the direction of motor rotation.

IF THE MOTOR MOTION IS ERRATIC, Check For:

Supply voltage out of tolerance.

Improper motion parameters (low speed, acceleration/deceleration, jog speed, home speed and feed rate). Set parameters on controller supplying pulse input to drive.

Filter capacitor missing or too low in value.

IF TORQUE IS LOW, Check For:

All Windings Off active.

Correct current setting.

Improper supply voltage.

IF "FAULT" INDICATOR IS LIT, Check For:

Improper motor wiring

Grounded or shorted wiring to the motor or shorted motor

Improper motor type or incorrect Current Select switch setting

If a malfunction occurs that cannot be corrected by making the preceding checks, contact Customer Support.

APPENDIX A: TROUBLESHOOTING ELECTRICAL INTERFERENCE PROBLEMS

Electrical interference problems are common with today's computer based controls, and such problems are often difficult to diagnose and cure. If such a problem occurs with your system, the following checks should be made to locate the cause of the problem.

1. Check the quality of the AC line voltage using an oscilloscope and a line monitor. If line voltage problems exist, use appropriate line conditioning, such as line filters or isolation transformers.
2. Follow proper wiring practices for location, grounding, wiring and relay suppression.
3. Double-check the grounding connections to be sure they are good electrical connections and are as short and direct as possible.
4. Try operating the drive with all suspected noise sources switched off. If the drive functions properly, switch the noise sources on again, one at a time, and isolate the one(s) causing interference problems. When a noise source is located, try rerouting wiring, suppressing relays or other measures to eliminate the problem.

Distribution Coast-to-Coast and International

Danaher Motion products are available nationwide through an extensive authorized distributor network. These distributors offer literature, technical assistance and a wide range of models off the shelf for fastest possible delivery.

Danaher Motion sales engineers are conveniently located to provide prompt attention to customers' needs. Call the nearest office listed for ordering and application information or for the address of the closest authorized distributor.

IN U.S.A. AND CANADA

Danaher Motion
13500-J South Point Blvd.
Charlotte, NC 28273
Tel: (704) 588-5693
FAX: 704-588-5695
Email: sales2@danahermotion.com
Web: www.DanaherMotion.com

IN EUROPE

Danaher Motion GmbH & Co. KG
Robert-Bosch-Straße
64331 Weiterstadt, Germany
Tel: +49 (0) 6151-8796-10
Fax: +49 (0) 6151-8796-123
Web: www.DanaherMotion.de



© 1994 - 2003, Danaher Motion